1500S - OPERATING INFORMATION





ATTENTION IF RED LIGHTS ARE FLASHING PLEASE ATTEND MACHINE.

TO RESOLVE DO THE FOLLOWING:

1. INSTRUCTIONS DISPLAYED ON SCREEN

Follow instructions displayed on coffee machines screen to clear the message

OR. 2. DRINKS DISPLAYED ON SCREEN

If the lights are flashing red and the Symbol is displayed in the top right part of the screen, above the drinks, then press this symbol, and follow instructions displayed on coffee machines screen to clear the message.



REMOVING GROUTS CONTAINER

IMPORTANT PROCESS

REMOVAL OF GROUTS

- 1. Lift the dispense spout (foamer) to its highest position
- 2. Remove and empty the grouts container, wiping down the inside
- 3. Carefully replace the grouts container back into the machine
 - 4. Confirm on the display that container has been emptied
 - 5. Lower the dispense spout (foamer) to the cup position



SPOUT LOWERED BACK TO READY POSITION



1. ACCESSING THE CLEANING MENU

A. FINDING MENU



- 1. Gently double tap the bottom right of screen
- 2. Select the home icon when it displays
- 3. Select the care options tab



B. CLEANING OPTIONS

	Care	
Cleaning programs	Selection of different cleaning programs	
CleanLock	Touch display switch-off for display cleaning	
Instructions	Cleaning animations	
CLEANING PROGRAMS	CLEANLOCK	INSTRUCTIONS

Different cleaning options

- 1. System cleaning
- 2. Mixer rinsing
- 3. Milk system rinsing
- 4. Foamer rinsing

A 15-second countdown starts and the screen is deactivated. The touch display can now be cleaned by wiping action.

Animated instructions for the weekly cleaning procedures, includes choc mixer and combi spout.

2. END OF DAY **CLEANING PROCESS**

SYSTEM CLEANING

End Of Day Cleaning Process. This needs to be performed daily. NOTE: WMF blue cleaning container is required for cleaning. **PROCESS**

- Access the Care menu 1.
- Touch Cleaning programs 2.
- Touch System cleaning 3.
- 4. Follow prompts to setup - Information / instructions will be shown on the display
- 5. Machine will perform clean cycle -Up to 14 mins
- 6. Pack away the cleaning containers



CAFIZA TABLET INSERTED FOR BREWER



RINZA TABLET INSERTED FOR MILK SYSTEM. DO NOT ADD WATER.

3. CLEANING INTERVALS **OVERVIEW**





For further information please refer to care menu instructions or user manual

VERSION. 3.4.17

System will progress with cleaning

(up to 14 minutes max)



END OF DAY SYSTEM CLEAN



PERFORM THIS AT LEAST ONCE EVERY 24 HOURS



THIS CLEANING PROCEDURE TAKES APPROX. 14 MINUTES



CHECK CORRECT TABLET IS USED FOR EACH STAGE. USE ONLY URNEX TABLETS.



top chute for brewer cleaning

Part No: 12-E18UX100-12 Cafiza E18

Plug each milk line into the matching blue WMF cleaning container



END OF DAY SYSTEM CLEAN



PERFORM THIS AT LEAST **ONCE EVERY 24 HOURS**



THIS CLEANING PROCEDURE TAKES APPROX. 14 MINUTES



CHECK CORRECT TABLET IS USED FOR EACH STAGE. USE ONLY URNEX TABLETS.



IMPORTANT : MILK ACTIVATION If you have selected 'No' at Step 4.



Select 'Release Milk System'

VERSION. 3.2.18



MILK SYSTEM EXCHANGE & CLEAN



STEP 1.

PERFORM THIS AT THE END OF THE WEEK.



STEP 5.

THIS CLEANING PROCEDURE TAKES APPROX. 15 MINUTES



STEP 3.

USE ONLY WMF CERTIFIED MILK CLEANING TABLETS.

Disconnect the milk line from the foamer



Remove combi spout & remove milk hose



Separate foamer into separate pieces ready for soaking



Re-mount the spare clean foamer, choc hose & milk line

STEP 7.



Store in tub with lid to avoid contamination ready for next weekly exchange



Fill container with warm water and add one RINZA tablet. Place dirty foamer & milk line, soak for 5 hours



After soaking, rinse all pieces under tap and dry

VERSION. 1.1.17



HOPPER CLEANING



PERFORM THIS AT THE END OF THE MONTH.



THIS CLEANING PROCEDURE TAKES APPROX. 15 MINUTES



ENSURE HOPPERS ARE DRY BEFORE RE-FITTING

STEP 1.



Open Display Panel

STEP 2.

STEP 5.



Turn pin left using the multi tool to release all hoppers

STEP 3.

D



Gently lift hoppers, empty the contents into a clean container



Hand wash hoppers & dry thoroughly

STEP 7.



Close Display Panel



Refill hopper with product and place onto machine





Turn the lock system to the right to re-lock hoppers

IMPORTANT: CHOCOLATE HOPPER REASSEMBLY

Please note, once you have dried the hopper after washing, it is important that the hopper is reassembled correctly for proper functioning. Please use the exploded diagram as a guide for reassembly and make sure that the half moon opening is at the top before re-inserting the hopper.



VERSION. 2.2.14



CHOCOLATE WHIPPER/MIXER CLEANING



PERFORM THIS AT THE END OF THE WEEK.



THIS CLEANING PROCEDURE TAKES APPROX. 10 MINUTES



USE ONLY WMF CERTIFIED MILK CLEANING TABLETS.

